

# Elite

## Evo Floor Stand

### Getting Started Guide

Follow this guide to set up  
your Elite Evo Floor Stand.

# Evo Floor Stand

First, let's set up your Evo Floor Stand.  
Locate the below items and continue  
to Step 1.



Hinge pole



Base pole




Baseplate




x3 Baseplate  
screws




x2 Grub  
screws



**Step 1** Feed cable up through the hinge pole. Ensure enough length is fed through to easily plug into your tablet.



**Step 2** Slide the hinge pole onto the base pole while feeding the cable through. Screw in grub screws to secure.



**Step 3** Screw on baseplate with baseplate screws with the charging cable running underneath.

# Elite Holder

Follow these steps if you have purchased the Elite holder. Locate the below items along with your tablet device and charging cable and continue to Step 1.




Elite holder




Keys



x4 Screws




**Step 1** Locate the Elite holder and attach to the hinge and screw in the x4 screws to secure.



**Step 2** Unlock the Elite Holder with keys provided and, if applicable, slide the latch to remove the faceplate.




**Step 3** Remove the faceplate.



**Step 4** Plug in your tablet while placing it into the holder.




**Step 5** Place faceplate back on the case.



**Step 6** Lock the faceplate with keys provided before use.


# Extras

Follow these steps to install the cable cutout, tilt adjustment or rotation lock (for Evo X only).




**Cable Cutout** Unscrew existing closed cable cutout and install the open cable cutout included with stand.

Evo X Only



**Tilt Adjustment Lock** Using Allen key provided, tighten screw at desired angle to lock in position.

Evo X Only



**Rotation Lock** To lock rotation, remove holder and screw lock screw as shown to lock. Then attach the holder in desired position.



US Customer Support

**1800 293 9703**

[sales@bosstab.com](mailto:sales@bosstab.com)

Australia Customer Support

**1800 870 132**

[sales@bosstab.com.au](mailto:sales@bosstab.com.au)

**Warranty & Returns** If you receive an item that is faulty or damaged then you can send it back for a refund, replacement or store credit and we'll pay for the return postage costs. We offer a 12 month warranty on items that are deemed defective by the manufacturer. If you have a defective product covered by this warranty, we will either repair using new or refurbished parts, or if repair is not possible, replace the item. The warranty will not cover loss or theft, nor damage deemed to be caused by misuse or unauthorized modification. To view our full returns policy and initiate a return please visit **[www.bosstab.com](http://www.bosstab.com)**