


Gemini

Getting Started Guide


Follow this guide to set up your double sided Gemini stand with Elite or Touch.

Elite


Follow this guide to set up your Elite holder with the Gemini stand. Repeat steps for both front and back facing holders if needed.




Step 1 Place Elite holder onto Gemini stand and screw in 4 screws to secure.




Step 2 Unlock holder with keys provided and remove faceplate.




Step 3 Feed charging cable through the stand and plug in your tablet while placing it into the Elite holder.



Step 4 Place faceplate back on and lock.




Drill pilot holes and hole for cable routing if needed for screw mounting.




Screw in Wood Screws to mount your stand.

Touch


Follow this guide to set up your Touch holder with the Gemini stand. Repeat steps for both front and back facing holders if needed.




Step 1 Unscrew top bracket that holds the adhesive and separate.




Step 2 Peel off adhesive & place the bracket in the center of your tablet. Press & hold for 20 seconds.




Step 3 Place Touch holder onto Gemini stand and screw in 4 screws to secure. Feed charging cable through the stand.



Step 4 Re-attach top bracket and secure with the lock screw. Plug in the charging cable.




Drill pilot holes and hole for cable routing if needed for screw mounting.




Screw in Wood Screws to mount your stand.


Follow these steps to install the Gemini Dual Arm.



Step 1 Remove the magnetic panel from your Gemini Stand.




Step 2 Pop out the cover plate.




Step 3 Screw in the Gemini Dual Arm using 4 screws provided. Then, repeat the steps for the holder to install either the Elite or Touch holder on the Gemini Dual Arm.

Optional Extras



Cable Cutout

Unscrew existing closed cable cutout & install the open cable cutout included with stand.



Cable Management

For power bank and PoE access, remove the magnetic panel for access to the cable channel.



US Customer Support

1800 293 9703

sales@bosstab.com

Australia Customer Support

1800 870 132

sales@bosstab.com.au

Warranty & Returns If you receive an item that is faulty or damaged then you can send it back for a refund, replacement or store credit and we'll pay for the return postage costs. We offer a 12 month warranty on items that are deemed defective by the manufacturer. If you have a defective product covered by this warranty, we will either repair using new or refurbished parts, or if repair is not possible, replace the item. The warranty will not cover loss or theft, nor damage deemed to be caused by misuse or unauthorized modification. To view our full returns policy and initiate a return please visit www.bosstab.com